

# ECE411 Group 6-- Voice Modulator Device

**Authors:** Philip Arola, Aaron Chan, Ryan Writz, Jordan Bergmann, Stephen Johnston

## Revision History

Revision	Changes	Date	Author
0.1	Initial revision	11/28/18	Philip Arola

## Table of Contents

Revision History .....	1
1 Introduction .....	2
1.1 Objective .....	2
1.2 Reference Material (datasheets) .....	2
2. Test Equipment .....	2
2.1 Equipment Setup.....	2
3. Test Procedures .....	3
3.1 Power-on Test.....	3
3.2 Functional Test.....	3
3.3 Human Ear Test.....	3
4 Appendix: Test Records.....	4
4.1 Functional Test.....	4
4.2 Human Ear Test.....	5

## 1 Introduction

This device is a voice modulator, designed to be reprogrammable using the ISCP pins, allowing the end user to change the modulation that takes place. It takes in a single microphone input, and outputs a single speaker line. It also has indicator LEDs to indicate power.

### 1.1 Objective

The objective of this document is to provide a procedure to validate that the device operates properly and safely. We do this by testing the I/O from a black box perspective, and by testing power inputs.

### 1.2 Reference Material (datasheets)

- Atmel ATmega48 datasheet
- MCP4921 12 bit DAC datasheet
- MCP3208 16 bit ADC datasheet

## 2. Test Equipment

1. Oscilloscope
2. Function Generator
3. Power supply
4. Test cables and probes

### 2.1 Equipment Setup

- 1 Set power supply to a ~5V output, with at least half an amp of allowed output
  - a. Hook up a partially stripped USB 3.0 Mini Type-B to the power supply output, and plug in the USB end into the USB header on the board
  - b. Alternatively, use a normal, unstripped USB 3.0 Mini Type-B with a USB Type-A connector, and plug into a laptop or cell-phone charger
- 2 Set function generator to produce frequency sweep from 100 Hz to 20 KHz
  - a. Hook up the probes to a partially stripped aux cord, and plug into the microphone input on the board
- 3 Hook the oscilloscope probes onto the appropriate probe test points on the board

### 3. Test Procedures

#### 3.1 Power-on Test

1. Ensure power supply is connected as described in 2.1 [Equipment Setup], subsection 1.
2. Turn on the power supply
3. All three power indication LEDs should turn on

#### 3.2 Functional Test

1. Ensure power supply is connected as described in 2.1 [Equipment Setup], subsection 1.
2. Ensure the function generator is connected as described in 2.1 [Equipment Setup], subsection 2.
3. Ensure the oscilloscope is connected as described in 2.1 [Equipment Setup], subsection 3.
4. Turn on the power supply, function generator, and the oscilloscope
5. Observe the oscilloscope measurements, and ensure the frequency of the output roughly matches the input
  - a. The match will not be perfect, as the microcontroller purposefully introduces noise/modulation as part of the functionality. The fundamental frequency should remain the same.

#### 3.3 Human Ear Test

This test will simply consist of the user speaking into the microphone and listening to the output. The test passes if the modulation sounds right. This is a very subjective test and should be run alongside Functional Test 3.2 as a supplement.

## 4 Appendix: Test Records

### 4.1 Functional Test

Test Writer	Philip Arola					
Test Case Name	Functional test				Test ID	I/O-Waveform
Description	Ensure the waveform produced by the system is what is expected				Type	Black Box X White Box
Test Information						
Name of Tester					Date	
Relevant Version #					Time	
Setup	Ensure power supply is connected as described in 2.1 [Equipment Setup], subsection 1.					
Additional Equipment	Power Supply, Function Generator, Oscilloscope					
Stage	Operation	Expectation	P	F	/	Comment
1	Observe waveforms	Fundamental frequencies match				
2						
3						
Overall results						

#### 4.2 Human Ear Test

Test Writer	Philip Arola					
Test Case Name	Human Ear Test			Test ID	I/O-Audio	
Description	Verify that the output of the device is intelligible to the human ear			Type	Black Box	X
					White Box	
Test Information						
Name of Tester				Date		
Relevant Version #				Time		
Setup	<ol style="list-style-type: none"> <li>1. Ensure power supply is connected as described in 2.1 [Equipment Setup], subsection 1.</li> <li>2. Ensure the function generator is connected as described in 2.1 [Equipment Setup], subsection 2.</li> <li>3. Ensure the oscilloscope is connected as described in 2.1 [Equipment Setup], subsection 3.</li> </ol>					
Additional Equipment	Power Supply					
Stage	Operation	Expectation	P	F	/	Comment
1	Listen to the audio	Voice sounds like a dalek				
2						
3						
Overall results						